FAST™

AEMS

UNITY™

## ⓘ PRODUCT OVERVIEW

The FAST™ AEMS positions Holosun™ AEMS™ optics at a 2.26" optical centerline from the rail. It comes standard with a 2 cross bolt rail clamp, but is compatible with the FAST™ QD (Quick Detach) Lever.

One (1) FAST™ AEMS

Four (4) Optic Mounting Screws

Two (2) Washers

One (1) Rail Clamp

Two (2) Clamp Screws

1 Using the UNITY™ supplied Optic Mounting Screws, install the optic to the mount as shown. **Do not exceed manufacturer's recommended torque spec.**

2 Place the FAST™ AEMS mount on the M1913 Rail in desired location. If using the included Rail Clamp, move to step 3. If using the optional FAST™ QD Lever (sold separately), jump to step 4.

3 Insert each Clamp Screw through a Washer. Then insert them through the FAST™ AEMS mount and thread them into the Rail Clamp. Secure screws using a T25 bit driver. Lightly snug all screws before applying final torque to any. **Torque to 35 in-lbs (4 Nm).**

4 Optional FAST™ QD (Quick Detach) Lever (sold separately) can be installed in place of the Rail Clamp. Installation instructions are included with the lever.

UNITY™

LIFETIME GUARANTEE

MADE IN THE USA